




jumper	addr range
000	0x000 – 0x0ff
001	0x100 – 0x1ff
010	0x200 – 0x2ff
011	0x300 – 0x3ff
100	0x400 – 0x4ff
101	0x500 – 0x5ff
110	0x600 – 0x6ff
111	0x700 – 0x7ff

A Simple 80c49 ROM Reader